



ew 100 G4

- Quick Guide

Kurzanleitung

Guide rapide

Guida rapida

Guia de inicio rápido

Guia rápido

Beknopte handleiding

Krótká instrukcja obsługi

Snabbguide
- Kort vejledning

Παράρτημα

Γρήγορος οδηγός

Kısa Kılavuz

Краткая инструкция


快速指南

快速使用指南

クイックガイド

퀵 가이드

SENNHEISER



Sennheiser Documentation App



ANDROID APP ON Google play

Available on the App Store

or online at www.sennheiser.com/download
ew 100 G4_

Sennheiser electronic GmbH & Co. KG


Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 03/18, 575860/A02


EM 100



SKM 100




SKM 100-S





SK 100



Battery






Low Battery




	100 %	> 8 h
	70 %	4 - 6 h
	30 %	2 - 3 h
LOW BATT		

Setup




On





Off




Menu



Standard display



Menu



Auto lock

EM

1 2 3

Locked Unlock?

SET SET

SK

1 2 3

Locked Unlock?

SET SET

SKM

1 2 3

Locked Unlock?

SET SET

10 s Auto lock

Instruction Manual

Mute

EM 100

Instruction Manual

short

RX Mute On?

RX Mute Off?

SET

SKM 100

short

RF Mute On?

RF Mute Off?

SET

New frequency

Squelch

1

High Middle Low

40 25 10 RF

Instruction Manual

Change frequency

2 SKM/SK off!

3

Easy Setup EM	Frequency Preset EM, SK, SKM
Menu SET Easy Setup	Menu SET Frequency Preset B.Ch: 1.1
Easy Setup SET Scan New List	Frequency Preset SET B.Ch: 15.6 767.900 MHz
Scan New List 734 ... 776 MHz WAIT 30s	Frequency Preset SET B.Ch: 15.6 767.900 MHz
Easy Setup SET Bank 1 ... 20 Free: 0 ... 12	Stored
Easy Setup SET B.Ch: 1. 1...12 Sync 758.200 MHz	
Stored	

No frequency 1 Squelch: Middle ... Instruction Manual

Sync

4

Instruction Manual

Instruction Manual

Instruction Manual

SK 100

Menu SET
Advanced

Advanced SET
Mute Mode
AF On/Off

Mute Mode SET
AF On/Off

SK only:

Mute Mode SET
RF On/Off

AF Mute

Mute On

Mute Off

RF Mute

Mute On

Mute Off

SKM 100-S

Multichannel - Easy Setup

Bank 1 ... 20; U
Channel 1 ... 12

max. 12 channels

>12 channels Instruction Manual

RJ 10

Instruction Manual

Sensitivity

5

Menu
Sensitivity
-24dB

-60 dB ... 0 dB

-48 dB ... 0 dB

AF PEAK

Instruction Manual

AF out

6

Menu
AF Out
+18 dB

LEVEL

-24 dB ... +24 dB

Instruction Manual

SKM

ME 2 | ME 4

ME 2

25 cm (10")

ME 4

ME 3-II

2...3 cm (1")